



Pictures reference only

PARTS NUMBER	DESCRIPTION	QTY	EFFECTIVE DATE
1 11341-LEA-000	N/A L. CRANK CASE COVER	1	
2 11346-HMA-000	L. BEARING SETTING PLATE	1	
3 1134A-LEA-000	L. CRANK CASE COVER ASSY.	1	
4 11351-LEA-000	L. OUTER COVER	1	
5 11352-LEA-000	L. OUTER COVER SPONGE	1	
6 11353-HMA-000	L. OUTER COVER SEAL	1	
7 1135A-LEA-000	L OUTER COVER ASSY.	1	
8 1137A-HMA-000	BEARING STAY COLLAR ASSY.	1	
8-1 11371-HMA-000	BERING STAY COLLAR	1	
8-2 91303-HMA-000	O-RING 26.5*2.0	1	
9 11395-LEA-000	L COVER GASKET	1	
10 96001-06012-00	FLANGE BOLT SH 6*12	2	
11 96001-06018-07	SH. FLANGE BOLT 6*18	7	
12 96001-06035-00	FLANGE SH BOLT 6X35	9	
13 96150-60060-10	RADIAL BALL BEARING 6006LLU	1	
15 17221-LEA-000	TRAP COMP	1	
16 11344-HMA-000	L COVER ELEMENT	1	